Callíngton

TECHNICAL DATA SHEET

BIOCLEAN 360SC Super Concentrate aircraft toilet deodoriser

DESCRIPTION



BIOCLEAN 360SC is a super concentrated toilet cleaning fluid, formulated to clean and deodorise aircraft lavatories. A state-of-the-art unique combination of detergents, scale inhibitor and deodorising properties prevents foul odours and keeps aircraft toilets clean and fully operational. This novel chemistry is VOC free and prevents ammonia and formaldehyde generation.

Ground handlers will benefit from improved hygiene safety in disposing of waste that has been correctly treated before removal from vacuum waste tanks. Passengers and crew will notice improved performance and hygiene from the toilet system.

FEATURES & BENEFITS



- Fast Acting and Long Lasting manufactured with powerful ingredients to start working immediately to control odours and reduce deposits in the toilet waste system and continue working throughout the flight.
- Long-lasting Air Freshener slow-release pine scent acts as a long-lasting deodorant and air freshener boosting performance every time the toilet is flushed.
- Low foaming during flush contains a powerful anti-foaming agent to eliminate toilet foaming within 20 seconds.
- Safe to use Will not stain fabrics, rubber, and plastic materials
- Biodegradable formulation safe for the environment
- Super Concentrated high dilution rate reduces chemical usage and environmental impact



TECHNICAL DATA SHEET

APPROVALS

- AMS 1476C
- Boeing BSS 7432

PROPERTIES:

| Appearance: | Clear, dark blue liquid |
|-------------|-------------------------|
| | |

Odour: Fresh pine odour

Shelf Life: 3 years from date of manufacture

APPLICATION:

BIOCLEAN 360SC is a highly concentrated product. It can be used for vacuum waste tanks or recirculating waste tanks. The recommended dilution for optimal performance is 1:640 depending upon the duration of the flight.

| | AIRCRAFT SIZE | | | |
|---------------------|---------------|-----------------|-----------------|---------------|
| SERVICING | Narrow Bodied | Wide Bodied | Wide Bodied | Super Jumbo |
| INTERVAL | (B737, | (B767, A330) | (B777, 787, | (A380) |
| | A319,320,321) | | A340, 350) | |
| Short haul flights | 30 – 50mL per | 50 – 80mL per | 50 – 80mL per | 80 – 100mL |
| (6 – 12 hours) | precharge | precharge | precharge | per precharge |
| | | | | |
| Medium haul flights | 50 – 80mL per | 80 – 100mL per | 80 – 100mL per | 100 – 120mL |
| (12 – 24 hours) | precharge | precharge | precharge | per precharge |
| | | | | |
| Long haul flights | 80 – 100mL | 100 – 120mL per | 100 – 120mL per | 100 – 120mL |
| (>24 hours) | per precharge | precharge | precharge | per precharge |
| | | | | |

Contact your Account Manager about a dosing rate specific to your requirements.

FIRST AID: Never give anything by mouth to an unconscious person. If you feel unwell, seek medical advice immediately (show the label where possible). IF INHALED: Assure fresh air breathing. Allow the victim to rest. IF ON SKIN: Remove affected clothing and wash all exposed skin area with mild soap and water, followed by warm water rinse. IF IN EYES: Rinse immediately with plenty of water. Remove contact lenses, if present and easy to do. Continue rinsing. Obtain medical attention if pain, blinking, or redness persist. IF SWALLOWED: Rinse mouth. Do NOT induce vomiting. Obtain emergency medical attention.

STORAGE: BIOCLEAN 360SC can be stored in a cool, dry, well-ventilated area.



DISPOSAL: Dispose of contents/drum in accordance with local/national regulations. Avoid release to the environment.

ORDERING INFORMATION

| Product Code | Packaging | Units/ Carton |
|--------------|-----------|-----------------------|
| 2319/30 | 1L | 12 x 1 L / per carton |
| 2319/42 | 5L | 4 x 5L / per carton |
| 2319/51 | 20L | Each |
| 2319/64 | 200L | Each |
| 2319/1000 | 1000L | Each |

WARRANTY – All statements, information and data presented herein are believed to be accurate and reliable but are not to be taken as a guarantee, expressed or implied, for which seller assumes legal responsibility and they are offered solely for your consideration, investigation and verification. Statements or suggestions concerning possible use of this product are made without representation or warranty that any such use is free of patent infringement and are not recommendations to infringe on any patent. Created 28 November 2022 Date Printed 9/01/2024 5:27 PM