

## TECHNICAL DATA SHEET

# Ki-ose<sup>®</sup> 390 SINGLE WIPE

## Dual Use Disinfectant Cleaner Wipe for Hands & Surfaces

### DESCRIPTION

Ki-ose<sup>®</sup> 390 Single Wipe is a unique convenient dual use antiseptic cleaning wipe for the disinfection of both hands and surfaces. Dermatologically tested and efficient disinfectant, Ki-ose<sup>390</sup> Single Wipe has been specially designed for use by the cabin crew and passengers during the flight. It is used by cabin attendants for many applications in galleys (surfaces in contact with food), all surfaces on trolleys, in lavatories, and in the cabin, and to sanitise their own hands. Ki-ose<sup>®</sup> 390 Single Wipe will not damage fabrics, plastics, metals, rubber or other surfaces.

Ki-ose<sup>®</sup> 390 Single Wipe can be personalised upon request (color, company logo...)



### FEATURES & BENEFITS

- Ready to use individual sachets.
- Non-flammable water-based formulation.
- Wide spectrum cleaner disinfectant for fast hand antiseptis of hands and disinfection of small surfaces and equipment.
- Dermatologically tested – safe for use on skin.
- Fully aircraft approved (Airbus, Boeing, DGA).
- 140 x 170 mm spunlace wipe, will not tear.
- Gentle floral fragrance.
- Kills 99.99% of most of harmful bacteria, viruses & fungi (see efficacy tests below).
- **Manufactured in the EU.**
- **Calculated and Compensated Carbon Footprint**



**CO<sub>2</sub> compensated**  
Product  
ClimatePartner.com/15744-2307-1001



### DIRECTION FOR USE:

#### - For hands:

- Rub over the whole hands surface and interdigital spaces, with the wipe, for at least 30 seconds. Let it dry. Do not rinse. External use on healthy skin only

#### - For surfaces and objects:

- Common surfaces: Rub the wipe on surfaces to be cleaned and disinfected. Let it dry. Do not rinse.
- Consumer utensils (cutlery...) and food preparation areas: Rub the wipe on surfaces to be cleaned and disinfected. Let it dry. Rinse with drinkable water.

*Use biocides with caution. Before use, read the label and information concerning the product.*

### PHYSICAL PROPERTIES

Active ingredient: 0.2% w/w didecyltrimethylammonium chloride n° CAS 7173-51-5  
Fragrance: Floral  
Wipe: 140 x 170 mm soft and stretchable spunlace (contains 60-70% PE)  
Shelf life: 24 months  
*Expiry date and batch number printed on the edge of each sachet*

## TECHNICAL DATA SHEET

### CERTIFICATIONS AND APPROVALS

- AMS 1453
- BSS 7434
- Approved by French DGA (Directorate General of Armaments)
- Complies with the EU directive n° 2019/904 on single use plastics.

### EFFICACY

BACTERICIDAL	
EN 1276	<i>Pseudomonas aeruginosa</i> , <i>Escherichia coli</i> ( <i>E.coli</i> is a surrogate to <i>V. cholerae</i> ), <i>Staphylococcus aureus</i> , <i>Enterococcus hirae</i> surrogated bacteria for Enterobacteria
EN 13727	<i>Pseudomonas aeruginosa</i> , <i>Escherichia coli</i> ( <i>E.coli</i> is a surrogate to <i>V. cholerae</i> ), <i>Staphylococcus aureus</i> , <i>Enterococcus hirae</i> surrogated bacteria for Enterobacteria
EN 13697	<i>Pseudomonas aeruginosa</i> , <i>Escherichia coli</i> ( <i>E.coli</i> is a surrogate to <i>V. cholerae</i> ), <i>Staphylococcus aureus</i> , <i>Enterococcus hirae</i> surrogated bacteria for Enterobacteria
EN 16615	<i>Pseudomonas aeruginosa</i> , <i>Staphylococcus aureus</i> , <i>Enterococcus hirae</i> surrogated bacteria for Enterobacteria
YEASTICIDAL	
EN 1650	<i>Candida albicans</i>
EN 16615	<i>Candida albicans</i>
FUNGICIDAL	
EN 13697	<i>Candida albicans</i> , <i>Aspergillus brasiliensis</i> surrogated fungus for <i>Aspergillus Niger</i>
VIRUCIDAL	
EN 14476	Influenza A (H1N1) surrogated virus for lipophilic viruses (Ebola, Coronavirus, Flu, Hepatitis, HIV, Rotavirus), vaccinia virus, murine norovirus, adenovirus
EN 16777	Adenovirus, murine norovirus

### ORDERING INFORMATION

Product Code	Product	Carton weight (Kg)	Units /carton	Carton dimensions (cm)	CO <sub>2</sub> / '000 units (EXW Paris)
4975/005	Ki-ose® <sup>390</sup> Single Wipe	6.0	1 000	39 x 34 x 19	12.79 Kg



**CONTACT US TO KNOW MORE ABOUT CARBON FOOTPRINT AND CARBON OFFSET FOR CO<sub>2</sub> NEUTRAL PRODUCTS**



### PRECAUTION

External use on healthy skin only. Keep out of reach of children. Do not eat, drink, or smoke when using this product. Material safety data sheet available on request.

### FIRST AID

If skin irritation or rash occurs: Get medical advice/attention. IF IN EYES: Rinse cautiously with water for several minutes. Obtain medical attention if pain, blinking or redness persists.

### STORAGE

Before opening, keep protected from the heat and at normal temperatures. Store in a dry place. Do not expose to temperatures exceeding 50°C/122°F.

**WARRANTY** – All statements, information and data presented herein are believed to be accurate and reliable but are not to be taken as a guarantee, expressed or implied, for which seller assumes legal responsibility and they are offered solely for your consideration, investigation and verification. Statements or suggestions concerning possible use of this product are made without representation or warranty that any such use is free of patent infringement and are not recommendations to infringe on any patent. Created 13 December 2019. Modified on 3<sup>rd</sup> July 2024. Date Printed 3/07/2024 5:59 PM