

Bio-hazard spill kits made easy

Callington **Universal Precaution Kit (UPK)** is complete with everything you need for an effective spill management system.

ICAO
& IATA

SINGLE USE

Designed for single use application



Compact and portable with tamper proof plastic packaging for added security



Suitable for all industries aged care, transport, health care, hospitality and offices

ICAO & IATA

Conforms to both ICAO and IATA recommendations



View our range of **videos** and **flyers** on our website



Find out more at callington.com or psa-paris.com

Callington

PSA
a Callington Group company

Universal Precaution Kit

DESCRIPTION

Callington Universal Precaution Spill Kit is a versatile spill cleaning kit, which readily supports the cleaning procedures for any bodily fluid incidents. The kit consists of an effective disinfectant cleaner & deodoriser, face/eye mask, long sleeve protective apron, disposable wipes, gloves, absorbent granules, absorbent cloth, plastic scoop and waste disposal bag.

FEATURES

- Conforms to both IATA & ICAO recommendations in the aviation industry and general industries.
- Instructional leaflet included
- Designed for single use application
- Packed in tamper proof plastic packaging for added security

CONTENTS

- Ki-ose 3-in-1 disinfectant, cleaner & deodoriser
- Face/eye mask (combined)
- Long sleeve protective apron
- Skin wipes
- Disposable nitrile gloves
- Absorbent granules
- Absorbent cloth
- Scoop and scraper
- Bio-hazard waste bag (with tie)
- Instructional leaflet

DIRECTIONS FOR USE

1. Put the gloves, protective apron and face/eye mask on.
2. Tear open the packet of absorbent granules and sprinkle the contents over the spillage. Allow time for the fluids to absorb.
3. Use the scoop & scraper to pick up the waste and deposit this into the bio-hazard bag.
4. Use the Ki-ose 3-in-1 disinfectant, cleaner & deodoriser together with cloth as necessary.
5. Once the waste has been removed, use the absorbent cloth to wipe the spillage area.
6. Place all used materials including the gloves into the waste disposal bag and seal it with the tie. Dispose of the bag properly.
7. Use the skin wipes to clean your hands, if required.

CERTIFICATIONS AND ACCREDITATIONS

IATA and ICAO recommendations for emergency precaution kits for aircrafts.

ORDERING INFORMATION

Item Code	Packaging	Regions
4852/PREKIT	48 x kits per carton	Global