

TECHNICAL DATA SHEET

ROX[®] 240 AG

Automotive Transmission Fluid Flush

DESCRIPTION

ROX[®] 240 AG contains a special formulation that helps clean and prepare all internal transmission components including the torque converter and transmission cooler prior to a new ATF being added.

FEATURES & BENEFITS

- Helps clean and prepare all internal transmission components
- Torque converter
- Convenient 250ml bottle

DIRECTIONS FOR USE

Engage emergency brake. Add one 250ml bottle of Callington ATF Flush to transmission oil fill port. Start engine and Idle for 10 – 15 Minutes. Circulate for 5 minutes cycling through all gears. Do NOT place vehicle under heavy load

Drain Completely. Filter must be changed prior to refilling with new transmission fluid. Refill with Automatic Transmission Fluid. **NOTE:** It is not recommended to flush transmissions that do not have a removable pan or access to the transmission filter.

PHYSICAL PROPERTIES

Density @ 20°C: 0.86 - 0.87 gms/ml
Appearance: Brown liquid
Transparency: Clear

FIRST AID

If swallowed DO NOT induce vomiting. Give a glass of water to drink. If on skin, wash with soap and water. In case of eye contact, flush thoroughly with water for at least 15 minutes. Contact a Doctor or Poisons Information Centre (Australia 131 126; New Zealand 0800 764 766). Combustible - DO NOT use near heat or open flame. Keep out of reach of children. Avoid skin & eye contact.

PRECAUTIONS & SAFETY INSTRUCTIONS

Combustible - DO NOT use near heat or open flame. Keep out of reach of children. Avoid skin & eye contact



WARRANTY – All statements, information and data presented herein are believed to be accurate and reliable but are not to be taken as a guarantee, expressed or implied, for which seller assumes legal responsibility and they are offered solely for your consideration, investigation and verification. Statements or suggestions concerning possible use of this product are made without representation or warranty that any such use is free of patent infringement and are not recommendations to infringe on any patent.
Created 8th September 2020 Date Printed 8/12/2020 1:44 PM